


Spill Guard Kits

50" Wide & 70" Wide

PARTS LIST



93970 Spill Guard Kit – 50" Wide							
Item	Part	Qty	Description	Item	Part	Qty	Description
1	93330	2	Spill Guard – 50" Wide	ns	93976	1	Bolt Bag – Spill Guard Kits, 50" Wide & 70" Wide
93975 Spill Guard Kit – 70" Wide							
2	93335	2	Spill Guard – 70" Wide	ns	93976	1	Bolt Bag – Spill Guard Kits, 50" Wide & 70" Wide
93976 Bolt Bag – Spill Guard Kits, 50" Wide & 70" Wide							
3		8	3/8-16 x 1 Carriage Bolt SS	5		12	3/8-16 x 3/4 Hex Cap Screw SS
4		20	3/8 Flat Washer SS Type A Wide	6		20	3/8-16 Hex Locknut GB SS
ns = not shown		G = Grade				SS = Stainless Steel	

INSTALLATION INSTRUCTIONS

⚠ WARNING

Do not exceed GVWR or GAWR ratings as found on the driver-side vehicle door cornerpost.

⚠ CAUTION


Read this document before installing the spill guard kit.

⚠ CAUTION

Use standard methods and practices when attaching spreader and installing accessories, including proper personal protective safety equipment.

NOTE: Apply anti-seize lubricant to all hardware to prevent galling.

1. Park the vehicle on a smooth, level, hard surface, such as concrete. Turn the vehicle ignition OFF and remove the key.
2. Remove the top screen.
3. Remove all the required knockouts on the spreader to create bolt holes for installation.
4. Install the spill guard on the top of the hopper, making sure that the holes on the bottom of the spill guard match the holes on the top of the hopper assembly.



5. Fasten the spill guard to the top of the hopper using 3/8" x 3/4" cap screws, 3/8" washers, and 3/8" locknuts. Leave fasteners loose.
6. Install 3/8" x 1" carriage bolts thru the side legs of the spill guard into the side of the hopper body or side of hopper extension, using 3/8" washer and 3/8" locknut. Leave fasteners loose.
7. Repeat on Steps 4–6 on the opposite side.
8. Tighten all fasteners.
9. Replace the top screen.

NOTE: Spill guards can be installed to the top of the hopper body or to the top of the side extensions.

Copyright © 2023 Douglas Dynamics, LLC. All rights reserved. This material may not be reproduced or copied, in whole or in part, in any printed, mechanical, electronic, film, or other distribution and storage media, without the written consent of the company. Authorization to photocopy items for internal or personal use by the company's outlets or spreader owner is granted.

The company reserves the right under its product improvement policy to change construction or design details and furnish equipment when so altered without reference to illustrations or specifications used. This equipment manufacturer or the vehicle manufacturer may require or recommend optional equipment for spreaders. Do not exceed vehicle ratings with a spreader. The company offers a limited warranty for all spreaders and accessories. See separately printed page for this important information.