
December 1, 2010 Lit. No. 48849, Rev. 00

Nylon Strap Kit

Low-Profile Tailgate Spreaders

PARTS LIST



94534 Nylon Strap Kit							
Item	Part	Qty	Description	Item	Part	Qty	Description
1		2	Lid Strap	3		8	M5 Flat Washer
2		8	#10-32 x 5/8 Machine Screw SS	4		8	10-32 Hex Locknut GB
SS = Stainless Steel							G = Grade

A CAUTION


Read this document before installing the nylon strap kit.

A CAUTION


Use standard methods and practices when attaching spreader and installing accessories including proper personal protective safety equipment.

INSTALLATION INSTRUCTIONS

- 1. Park the vehicle on a smooth, level, hard surface, such as concrete. Turn the vehicle ignition to the "OFF" position and remove the key.
- 2. Remove and discard old straps and hardware.
- 3. Find the end of the new nylon strap with the holes spaced closer together. Align this end with the holes in the hopper lid, such that the rest of the strap is towards the truck. The strap end should be placed between the rubber latch keeper bracket and the lid. Fasten using two #10 x 5/8" screws, two flat washers and two #10 locknuts. Repeat on other side.



4. Align the other end with the holes in the hopper tub. The strap should be placed between the rubber latch assembly and the tub. Fasten using two #10 x 5/8" screws, two flat washers and two #10 locknuts. Repeat on other side.



Copyright © 2010 Douglas Dynamics, L.L.C. All rights reserved. This material may not be reproduced or copied, in whole or in part, in any printed, mechanical, electronic, film or other distribution and storage media, without the written consent of the company. Authorization to photocopy items for internal or personal use by the company's outlets or spreader owner is granted.

The company reserves the right under its product improvement policy to change construction or design details and furnish equipment when so altered without reference to illustrations or specifications used. This equipment manufacturer or the vehicle manufacturer may require or recommend optional equipment for spreaders. Do not exceed vehicle ratings with a spreader. The company offers a limited warranty for all spreaders and accessories. See separately printed page for this important information.