



Gasoline Spreader Parts Kit

PRO-CASTER™ Spreaders

PARTS LIST

94890 Hopper Spreader Parts Kit					
Part	Qty	Description	Part	Qty	Description
94673	1	Loose Parts Bag	66426	1	Vehicle Wire Harness – 11 Pin
66860-1	1	Hopper Control Box – FE			
94673 Loose Parts Bag					
8329K	1	Dielectric Grease Tube	95597	1	Briggs and Stratton Owner's Manual and Warranty Statement
62057	1	Hook			
8291K	1	Plug Cover	94880	1	Honda Owner's Manual and Warranty Statement
20352	1	1/4" Insulated Blade Terminal			
66130	1	Rubber Grommet, 3/8" ID			

This Parts List is for FISHER® PRO-CASTER Hopper Spreaders with serial numbers beginning with 0806 and higher.

Copyright © 2013 Douglas Dynamics, LLC. All rights reserved. This material may not be reproduced or copied, in whole or in part, in any printed, mechanical, electronic, film or other distribution and storage media, without the written consent of Fisher Engineering. Authorization to photocopy items for internal or personal use by Fisher Engineering outlets or spreader owner is granted.

Fisher Engineering reserves the right under its product improvement policy to change construction or design details and furnish equipment when so altered without reference to illustrations or specifications used. Fisher Engineering or the vehicle manufacturer may require or recommend optional equipment for spreaders. Do not exceed vehicle ratings with a spreader. Fisher Engineering offers a limited warranty for all spreaders and accessories. See separately printed page for this important information. The following are registered (®) or unregistered (™) trademarks of Douglas Dynamics, LLC: FISHER®, PRO-CASTER™.

Printed in U.S.A.