

## SAFETY DEFINITIONS

### WARNING

Indicates a potentially hazardous situation that, if not avoided, could result in death or serious personal injury.

### CAUTION

Indicates a situation that, if not avoided, could result in minor personal injury and/or damage to product or property.

**NOTE:** Identifies tips, helpful hints and maintenance information the owner/operator should know.

## Before you Begin

- Park the vehicle on a level surface, place shift lever in PARK or NEUTRAL and set the parking brake.

The purpose of the CHMSL (Center High Mounted Stop Lamp) Isolation Relay Kit is to provide a signal source for the spreader CHMSL when the host vehicle's CHMSL circuit is not capable of providing the extra current. All vehicles with CHMSL shall have spreader CHMSL operating.

**NOTE:** This kit is applicable to 1994 and earlier vehicles. Also late model vehicles that do not provide a suitable CHMSL feed wire/connection point.

The host vehicle's authorized dealer or Body Builder Guide is the best source of information on suitable CHMSL signal electrical hook up location.

## SAFETY PRECAUTIONS

### WARNING

Do not install this product in deployment path of an air bag. Refer to vehicle manufacturer's manual for air bag deployment area(s).

### WARNING

**DO NOT** hook up directly to the host vehicle's stop lamp switch. Hooking up directly to the stop lamp switch may affect engine control, transmission control, anti-lock brakes, and the speed control module.

### CAUTION

Disconnect electric power before servicing or performing maintenance.

(Continued on other side.)

# CENTER HIGH MOUNTED STOP LAMP ISOLATION RELAY KIT INSTALLATION INSTRUCTIONS

63632


(Continued from other side.)

## INSTALLATION INSTRUCTIONS

(Refer to Wiring Diagram below.)

Locate the feed wire for the host vehicle's CHMSL. Pick a location for the relay which provides a short and convenient hook-up for ground, fused +12VDC, the spreader vehicle harness and the CHMSL signal. Make all the connections using the crimp terminals provided. **DO NOT USE INSULATION PIERCING CONNECTORS.** The butt splices provided are glue lined heat shrinkable. After all connections are finished and tested, use the provided wire wraps to secure the relay and wires.

### Wiring Diagram



Copyright© 2001 Douglas Dynamics, L.L.C. All rights reserved. This material may not be reproduced or copied, in whole or in part, in any printed, mechanical, electronic, film or other distribution and storage media, without the written consent of the company. Authorization to photocopy items for internal or personal use by the company's outlets is granted.

The company reserves the right under its product improvement policy to change construction or design details and furnish equipment when so altered without reference to illustrations or specifications used herein. The company and the vehicle manufacturer may require and/or recommend optional equipment for snow and ice control. The company offers a limited warranty for all spreaders and accessories. See separately printed page for this important information.